



Automatic Small Cotton Candy Machine Vending Type 2500W For Hotel / Food Shop

Our Product Introduction

Basic Information

- Place of Origin: Guangdong, China
- Brand Name: Xunying
- Model Number: XY-CC02
- Price: \$4,200.00/pieces 1-509 pieces



Product Specification

- Type: Coin Pusher
- Age: >3 Years, >6 Years, >8 Years
- Is_customized: Yes
- Plug Type: US PLUG
- Name: Cotton Candy Maker
- Suitable For: Amusement Game Center
- Material: Plastic
- Product Name: Cotton Candy Maker
- Warranty: 12 Months/Lifetime Maintenance
- Color: Picture
- Size: 1700*850*2100MM
- Voltage: 110V/220V/230V
- Player: 1 Player
- Weight: 180KG
- Highlight: **2500W Cotton Candy Machine.**

for more products please visit us on coin-gamemachine.com

Product Description

Products Description

Overview

Essential details

Condition:New

Showroom Location: China

Video outgoing-inspection: Provided

Machinery Test Report: Provided

Marketing Type: New Product

Warranty of core components: Not Available

Core Components: Motor

Brand Name: Xunying

Place of Origin: Guangdong, China

Voltage: 110V/220V

Power: 2500W

Dimension(L*W*H): 1600*750*2000MM

Weight: 300 KG, 350kg

Warranty: 1 Year

Application fields: Commercial catering, Snack food factory

Machinery Function: Cotton candy maker

Raw material: Sugar

Output product name: Cotton Candy

Key Selling Points: Automatic

Product name: Cotton Candy Machine

Picture Shows: Home Hotel Restaurant Bar Office

sugar storage: 300

Feature: High Prifit

Suitable for: Cinema Supermarket Amusement Park

Type: Vending machine

Cotton candy pattern: 24

Packaging Size: 1700*850*2100MM

Temperature control mode: Normal temperature

Applicable Industries: Hotels, Food & Beverage Factory, Restaurant, Home Use, Retail, Food Shop, Food & Beverage Shops, Other

PROJECT	PARAMETER	PROJECT	PARAMETER
POWER	800-2500W	MACHINE NET WEIGHT	300KG
WATER CONSUMPTION	IT TAKES 1 LITRE OF WATER TO CLEAN ABOUT 20 MARSHMALLOW S	GROSS WEIGHT MACHINE	370KG

SUGAR CONSUMPTION	ONE KILO OF SUGAR CAN MAKE 40-50 MARSHMALLOWS	USING THE ENVIRONMENT	THE ENVIRONMENT CAN BE USED BOTH INDOORS AND OUTDOORS
THE MACHINE SIZE	1320*670*2000MM	VOLTAGE	AC220V, 50 HZ. WE CAN CHANGE THE CORRESPONDING VOLTAGE FOR THE ACTUAL SITUATION OF YOUR COUNTRY .
PACKAGE SIZE	1420*770*1800MM	PATTERN	22 KINDS OF PATTERN

How to Play a Coin Pusher Cotton Candy Machine

Insert Coins:

Start by inserting your coins or tokens into the designated slot.

Observe the Machine:

Take a moment to observe the layout of the coins and prizes. Look for any piles that are close to the edge, as these are more likely to fall.

Control the Pusher:

Use the joystick or buttons to control the pusher mechanism. Move it left or right to align it with the coins you want to push.

Drop Coins Strategically:

When you're ready, press the button to drop a coin into the machine. Aim for areas where it will have the most impact on pushing other coins forward.

Watch for Movement:

After dropping the coin, watch closely to see how the coins move. If you see coins or prizes falling, cheer them on!

Repeat:

Continue to drop coins while observing the best spots to aim for. The goal is to push as many coins and prizes off the edge as possible.

Collect Your Prizes:

If you successfully push coins or tokens over the edge, they will fall into the collection tray. You can also win cotton candy or other prizes depending on the machine's design.

Tips for Success

Aim for Clusters: Target areas where coins are stacked or clustered together for a better chance of pushing them off.

Timing is Key: Wait for the right moment to drop your coin. Timing can affect how coins interact with each other.

Manage Your Coins: Keep track of how many coins you have left and strategize your drops accordingly.





Guangzhou Xunying Animation Technology Co., Ltd.



+86-15011936333



a770100411@gmail.com



coin-gamemachine.com

Guangzhou Panyu Mingjiang Hose Co., Ltd. (North of Xieshi Highway)